

How to Print, Scan and Copy

How to Authenticate at the MFP



Present Card against the reader where prompted to do so at the right of the LCD console

How to Release Prints at the MFP



Select Jobs to Print

Print All Jobs



Print Selection Screen

How to Use Copy & Scan Functionality

User Logout Button



Select Enable Device



Home Screen Button